Bridgeport Mill & Others

→ **NOTE** This Turbo Drive Table Feed is configured for mounting the feed on the right hand end of the table. The lead screw pitch is 5 turns per inch. See **CAUTION** below before changing anything!

CAUTION

The Turbo Drive power cable should be left **unplugged** until the drive is properly installed on the lead screw.

See the *Operation* manual to reverse the direction of travel or to change the lead screw pitch default. Turn **off** the Turbo Drive and **remove** the power plug from the wall before you attempt to change any jumpers or reverse the top housing.

WARNINGS

DO NOT install and operate this power feed without safety handwheel Servo #58923 on BOTH ends of the table. This is required to prevent injury.

Check handwheel clearances before operation.

Clearances between the surfaces of the handwheel and the non-moving parts of the equipment on which the handwheel is installed must be at least one-fourth inch (1/4") to prevent injury.

Do not operate without proper clearance!

Prevent contact during fast traverses.

WARRANTY CAUTION

There are *NO* user-serviceable parts inside the center or bottom housings. Removal of the motor, keyboard, or bottom housing screws *voids* the warranty.

REFERENCE DRAWINGS ENCLOSED

NA-58496 Bevel Gear Installation NB-58541 Turbo Drive Installation

0800-80678 Turbo Drive Operation manual

PREPARATION

Step 1: Gather together the following items that you will need to complete this installation.

- a) 3/8" electric hand drill
- b) 11/64" drill, 3/16" drill
- c) ball peen hammer & support piece
- d) flat file
- e) 3/4" socket wrench

- f) set of inch hex wrenches
- g) grease
- h) clean shop rag
- *Step 2:* Clean the power feed mounting area completely.
- **Step 3**: Remove the nut, handle, and dial assembly from the right hand end of the table. Keep the dial for reuse later.

MOUNTING HARDWARE INSTALLATION

- Step 1: Install the bearing retainer #6544 to the right side table bracket with three (3) #00675 screws.
- **Step 2**: Lubricate the shaft with a light coat of grease then slip the bearing race #0714 onto the lead screw shaft.
- Step 3: Slip the adaptor over the race to center it with the shaft. Keeping the portion of the race sticking out beyond the counterbored end of the adaptor so that it can be removed later, slide both pieces to locate the adaptor against the table bracket. Secure the adaptor with three 1/4-20 x 1" long socket head cap screws provided. Remove the bearing race.
- Step 4: Slip spacer #58539 onto the shaft followed by the bearing race as shown.

SHAFT EXTENSION AND TURBO DRIVE INSTALLATION

- Step 1: Screw on the shaft extension #57099 onto the lead screw and tighten.
- Step 2: Following the existing pilot hole, drill through the shaft extension using an 11/64" diameter drill. Finish the hole using a 3/16" diameter drill.
- Step 3: Support the other side of the hole with a heavy piece of metal and hammer in the #00596 roll pin. File smooth and clean thoroughly.
- Step 4: Slide the Turbo Drive onto the bearing race and push against the adaptor. Secure with two 1/4-20 x 1-1/8" long socket head cap screws.
 - *IF*: If the bearing race is not flush with the needle bearing in the unit within $\pm .05$ ", then either shim behind the race or machine the spacer to correctly locate the race.

BEVEL GEAR INSTALLATION

Step 1: Follow the drawing NA-58496 for installation of the bevel gear. Adjust for proper gear backlash.

DIAL AND HANDWHEEL INSTALLATION

Step 1: After getting the proper gear backlash, the dial should be adjusted to obtain .005" spacing from the face of the power feed. This is important in order to keep chips from entering

SERVO Turbo Drive Model 0200T Page 2

- the gear train. Three plastic (.030" thick) and five brass (.005" thick) washers are provided for this. Shim as required.
- Step 2: In the following sequence, install the key, dial and dial nut #59254. Slide the spacer #58540 and the handwheel #58923 in place and tighten with 1/2-20 locknut #01115.
- Step 3: Replace the handwheel on the left end of the table with the handwheel #58923 provided. This is required to prevent injury.

TURBO DRIVE OPERATION

See the separate **Servo Turbo Drive Operation** manual for complete operating instructions. Plug the unit into a properly grounded threewire outlet supplying 110 volt single phase 50/60 Hz 6 amp power. Turn the control switch ON and follow the instructions in the manual or on the **Quick Reference** sheet for setting limits.

SERVO PRODUCTS COMPANY

Web: www.servoproductsco.com

CALIFORNIA BRANCH 1355 W. Foothill Blvd.

Azusa, CA 91702 Ph. 626.691.0121 Fax 626.334.7301 **HEADQUARTERS**

34940 Lakeland Blvd. Eastlake, OH 44095 Ph. 440.942.9999 Fax 440.942-9100 FLORIDA BRANCH 8950 131st Ave. N.

Largo, FL 33773 Ph. 727.585.8555 Fax 727.585.6555

SERVO Turbo Drive Model 0200T Page 3



